







Model GRT01Z Parts List

Item No	Parts No.	Description	Q'ty
001	262054-7	URETHANE RING 3	1
002	256A96-7	GROOVED PIN 4B	1
003	268238-5	PIN 5	1
004	212009-2	NEEDLE BEARING 509	1
005	1412D1-0	MAGAGINE COVER COMPLETE	1
006	232924-4	COMPRESSION SPRING 11	1
007	312H72-4	REEL BEARING	1
008	941051-3	FLAT WASHER 4	1
009	266007-8	TAPPING SCREW BIND PT 3X10	1
010	233388-5	COMPRESSION SPRING 5	1
011	347D47-0	GUIDE PLATE	1
012	266007-8	TAPPING SCREW BIND PT 3X10	1
013	4131T9-3	MAGAZINE COVER LOCK	1
014	262054-7	URETHANE RING 3	1
015	256A93-3	GROOVED PIN 4A	1
016	266404-8	TAPPING SCREW BIND 3X14	2
017	312H73-2	REEL BASE	1
018	1410Y0-7	MAGNET HOLDER D COMPLETE	1
019	232921-0	COMPRESSION SPRING 4C	1
020	4131U3-2	PLATE COVER	1
021	266404-8	TAPPING SCREW BIND 3X14	2
022	268136-3	PIN 4	1
023	232925-2	TORSION SPRING 4A	1
024	347D33-1	SIDE PLATE	1
025	911008-8	PAN HEAD SCREW M3X8	2
026	1831L4-8	HOUSING SET	1
C10	263005-3	RUBBER PIN 6	2
C20	252126-6	HEX. LOCK NUT M4-7	2
C30	8091F2-9	CAUTION LABEL A	1
C40	8091F5-3	CAUTION LABEL B	1
C50	8091F1-1	INDICATION LABEL	1
D10		INC. 61	
027	256A89-4	SHOULDER PIN 4C	1
028	347D30-7	STOPPER BASE	1
029	232916-3	TORSION SPRING 4B	1
030	313610-7	STOPPER	1
031	911008-8	PAN HEAD SCREW M3X8	1
032	1410X5-0	MAGNET HOLDER C COMPLETE	1
033	911008-8	PAN HEAD SCREW M3X8	1
034	232922-8	COMPRESSION SPRING 4B	1
035	1410Y1-5	MAGNET HOLDER A COMPLETE	1
036	4131U6-6	SLIDE PLATE COVER	1
037	266007-8	TAPPING SCREW BIND PT 3X10	1
038	347D32-3	SLIDE PLATE	1
039	347D38-1	SLIDE PLATE GUIDE	1
040	266007-8	TAPPING SCREW BIND PT 3X10	1
041	458219-9	TRIGGER LOCK	1
042	234037-7	COMPRESSION SPRING 5	1
043	458220-4	TRIGGER	1
044	632W63-2	SWITCH UNIT	1
045	1411B8-6	CONTROLLER COMPLETE	1

046	632P65-6	TERMINAL UNIT	1
047	911008-8	PAN HEAD SCREW M3X8	1
048	266007-8	TAPPING SCREW BIND PT 3X10	1
049	232922-8	COMPRESSION SPRING 4B	1
050	1410Y1-5	MAGNET HOLDER A COMPLETE	1
051	4131U6-6	SLIDE PLATE COVER	1
052	347D32-3	SLIDE PLATE	1
053	266007-8	TAPPING SCREW BIND PT 3X10	1
054	347D38-1	SLIDE PLATE GUIDE	1
055	313610-7	STOPPER	1
056	347D30-7	STOPPER BASE	1
057	232916-3	TORSION SPRING 4B	1
058	256A89-4	SHOULDER PIN 4C	1
059	266130-9	TAPPING SCREW BIND PT 3X16	17
060	911008-8	PAN HEAD SCREW M3X8	2
061	1831L4-8	HOUSING SET	1
C10	263005-3	RUBBER PIN 6	2
C20	252126-6	HEX. LOCK NUT M4-7	2
C30	8091F2-9	CAUTION LABEL A	1
C40	8091F5-3	CAUTION LABEL B	1
C50	8091F1-1	INDICATION LABEL	1
D10		INC. 26	
062	266404-8	TAPPING SCREW BIND 3X14	2
063	4131U3-2	PLATE COVER	1
064	347D33-1	SIDE PLATE	1
065	268136-3	PIN 4	1
066	232925-2	TORSION SPRING 4A	1
067	266007-8	TAPPING SCREW BIND PT 3X10	2
068	266490-9	TAPPING SCREW PT 2X6	3
069	652069-6	FLAT HEAD SCREW M3X6	3
070	629D10-8	STATOR	1
071	619896-4	ROTOR	1
072	122K70-6	TWIST ASSEMBLY	1
073	266490-9	TAPPING SCREW PT 2X6	3
074	629D11-6	STATOR	1
075	652069-6	FLAT HEAD SCREW M3X6	3
076	619897-2	ROTOR	1
077	256A08-0	PIN 5	1
078	122K54-4	CURL GUIDE ASSEMBLY	1
079	1411G5-7	CUTTER COMPLETE	1
080	232923-6	COMPRESSION SPRING 4D	1
081	347D29-2	CUTTER BASE	1
082	313613-1	WIRE BENDER	1
083	313606-8	CUTTER GUIDE	1
084	265634-8	HEX SOCKET HEAD BOLT M3X8	4
085	313608-4	WIRE GUIDE B	1
086	347D34-9	CURL GUIDE C	1
087	265634-8	HEX SOCKET HEAD BOLT M3X8	1
088	327E72-3	SHOULDER SLEEVE 4B	1
089	122K71-4	RELEASE LEVER ASSEMBLY	1
090	253623-5	FLAT WASHER 9	1
091	327E71-5	SHOULDER SLEEVE 4A	1
092	922147-9	HEX. SOCKET HEAD BOLT M4X25	1
093	122K72-2	FEED GEAR BASE ASSEMBLY	1
094	232919-7	COMPRESSION SPRING 6	1
095	253632-4	FLAT WASHER 7	2

096	137328-4	SPUR GEAR 21 ASSEMBLY	2
097	253077-6	FLAT WASHER 6	2
098	961011-9	STOP RING E-4	2
099	313603-4	WIRE GUIDE A	1
100	266080-8	HEX. SOCKET HEAD BOLT M3X12	2
101	4131T8-5	GEAR COVER	1
102	265E18-0	H.S.H.BOLT M3X17	1
103	8151G4-2	GRT01 NAME PLATE	1
104	8151G8-4	GRT01 SERIAL NO. LABEL	1
A02	266622-8	TRUSS HEAD SCREW M4X12	1
A03	347D31-5	HOOK	1
A04	783208-8	HEX. WRENCH 2.5	1